



How to Check your WiFi Frequency

1. Connect your PC to the WiFi



2. Once connected, click on properties



3. Scroll down to find the information

